

Summary of product characteristics for a biocidal product

Product name: Superfucid express WIPES

Product type(s): PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT04 - Food and feed area (Disinfectants)

Authorisation number: EU-0027676-0000

R4BP 3 asset reference number: EU-0027676-0000

Table Of Contents

Administrative information	1
1.1. Trade names of the product	1
1.2. Authorisation holder	1
1.3. Manufacturer(s) of the biocidal products	1
1.4. Manufacturer(s) of the active substance(s)	2
2. Product composition and formulation	3
2.1. Qualitative and quantitative information on the composition of the biocidal product	3
2.2. Type of formulation	3
3. Hazard and precautionary statements	3
4. Authorised use(s)	4
5. General directions for use	8
5.1. Instructions for use	8
5.2. Risk mitigation measures	8
5.3. Particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment	8
5.4. Instructions for safe disposal of the product and its packaging	9
5.5. Conditions of storage and shelf-life of the product under normal conditions of storage	9
6. Other information	9

Administrative information

1.1. Trade names of the product

Superficid express WIPES
Bactesil Wipes
IPA Express Wipes
Twoalko Express Wipes
MicrobaX Express Wipes
Alkodes Express Wipes
Septokil Express Wipes
Mastersept Express Wipes
Descoficid Wipes
Bactoficid Express Wipes
Supergerm Express Wipes
Superdes Express Wipes
APESIN express F wipes

1.2. Authorisation holder

Name and address of the authorisation holder	Name	Lysoform Dr. Hans Rosemann GmbH
	Address	Kaiser-Wilhelm-Str. 133 12247 Berlin Germany
Authorisation number	EU-0027676-0000	
R4BP 3 asset reference number	EU-0027676-0000	
Date of the authorisation	27/06/2023	
Expiry date of the authorisation	31/07/2032	

1.3. Manufacturer(s) of the biocidal products

Name of the manufacturer	Lysoform Dr. Hans Rosemann GmbH,
Address of the manufacturer	Kaiser-Wilhelm-Str. 133 12247 Berlin Germany
Location of manufacturing sites	Lysoform Dr. Hans Rosemann GmbH, Kaiser-Wilhelm-Str. 133 12247 Berlin Germany
	A.F.P. Antiseptica Forschungs- und Produktionsgesellschaft mbH, Otto-Brenner-Straße 16-18 21337 Lüneburg Germany
	Sterisol AB, Kronoängsgatan 3 S 59223 Vadstena Sweden

1.4. Manufacturer(s) of the active substance(s)

Active substance	1354 - Propan-1-ol
Name of the manufacturer	OQ Chemicals GmbH (formerly Oxea GmbH)
Address of the manufacturer	Rheinpromenade 4a 40789 Monheim am Rhein Germany
Location of manufacturing sites	OQ Chemicals Corporation (formerly Oxea Corporation), 2001 FM 3057 TX 77414 Bay City United States

Active substance	1354 - Propan-1-ol
Name of the manufacturer	BASF SE
Address of the manufacturer	Carl-Bosch-Str. 38 67056 Ludwigshafen Germany
Location of manufacturing sites	BASF SE, Carl-Bosch-Str. 38 67056 Ludwigshafen Germany

Active substance	1355 - Propan-2-ol
Name of the manufacturer	INEOS Solvent Germany GmbH
Address of the manufacturer	Römerstrasse 733 47443 Moers Germany
Location of manufacturing sites	INEOS Solvent Germany GmbH, Römerstrasse 733 47443 Moers Germany
	INEOS Solvent Germany GmbH, Shamrockstrasse 88 44623 Herne Germany

2. Product composition and formulation

2.1. Qualitative and quantitative information on the composition of the biocidal product

Common name	IUPAC name	Function	CAS number	EC number	Content (%)
Propan-1-ol		Active Substance	71-23-8	200-746-9	14,3
Propan-2-ol		Active Substance	67-63-0	200-661-7	63,14

2.2. Type of formulation

AL - Any other liquid

3. Hazard and precautionary statements

Hazard statements	<p>Highly flammable liquid and vapour.</p> <p>Causes serious eye damage.</p> <p>May cause drowsiness or dizziness.</p> <p>Repeated exposure may cause skin dryness or cracking.</p>
Precautionary statements	<p>Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. - No smoking.</p>

Keep container tightly closed.

Avoid breathing vapours.

Use only outdoors or in a well-ventilated area.

IF INHALED: Remove person to fresh air and keep comfortable for breathing.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Immediately call a POISON CENTER/doctor.

Store in a well-ventilated place. Keep cool.

Store locked up.

Dispose of contents to an authorised waste collection point.

4. Authorised use(s)

4.1 Use description

Use 1 - hard non-porous small surface disinfection RTU wipes

Product type	PT02 - Disinfectants and algacides not intended for direct application to humans or animals (Disinfectants)
Where relevant, an exact description of the authorised use	Not relevant
Target organism(s) (including development stage)	<p>Scientific name: other Common name: Bacteria Development stage:</p> <p>Scientific name: other Common name: Yeasts Development stage:</p> <p>Scientific name: other Common name: Enveloped viruses Development stage:</p>
Field(s) of use	<p>Indoor</p> <p>Health care facilities and pharmaceutical and cosmetic industry, for example patient-near surrounding, working areas/desks, general equipment (excluding food contact surfaces): disinfection of small hard/non-porous surfaces For professional use only.</p>
Application method(s)	<p>Method: Manual application Detailed description:</p> <p>Ready-to-use disinfectant wipes at room temperature (20±2 °C) . The surface to be disinfected is wiped and wetted with a sufficient amount of the product, ensuring complete Coverage.</p>

Application rate(s) and frequencies

Application Rate: Minimum exposure time: for the control of bacteria, yeasts and enveloped viruses: 60 sec; Make the surface completely wet.
Dilution (%): Ready-to-use product
Number and timing of application:
A reasonable frequency of disinfection in a patient's room is 1-2 per day. Maximum number of applications is 6 per day. No safety intervals need to be considered between the application phases.

Category(ies) of users

Industrial
Professional

Pack sizes and packaging material

Dispenser of PE composite foil with screwed-in PE cap, containing 100 PP/PE wipes.

4.1.1 Use-specific instructions for use

Surfaces should always be visibly clean prior to disinfection. Maximum number of applications is 6 per day.

4.1.2 Use-specific risk mitigation measures

See general directions for use.

4.1.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

See general directions for use.

4.1.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

See general directions for use.

4.1.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

See general directions for use.

4.2 Use description

Use 2 - hard non-porous small surface disinfection RTU wipes

Product type	PT04 - Food and feed area (Disinfectants)
Where relevant, an exact description of the authorised use	Not relevant
Target organism(s) (including development stage)	Scientific name: other Common name: Bacteria Development stage: Scientific name: other Common name: Yeasts Development stage:
Field(s) of use	Indoor Health care facilities and food industry, for example patient-care surrounding, food preparation and handling in kitchens/restaurants): disinfection of small hard/non-porous surfaces. For professional use only.
Application method(s)	Method: Manual application Detailed description: Ready-to-use disinfectant wipes at room temperature (20±2 °C) . The surface to be disinfected is wetted with a sufficient amount of the product by wiping, ensuring complete coverage.
Application rate(s) and frequencies	Application Rate: Minimum exposure time: for the control of bacteria and yeasts at 20°C: 60 sec; Make the surface completely wet. Dilution (%): Ready-to-use product Number and timing of application: The product can be used as often as necessary. A reasonable frequency of disinfection in kitchens is 1-2 per day. No safety intervals need to be considered between the application phases.

Category(ies) of users	Industrial Professional
Pack sizes and packaging material	Dispenser of PE composite foil with screwed-in PE cap, containing 100 PP/PE wipes.

4.2.1 Use-specific instructions for use

Surfaces should always be visibly clean prior to disinfection.

4.2.2 Use-specific risk mitigation measures

See general directions for use.

4.2.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

See general directions for use.

4.2.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

See general directions for use.

4.2.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

See general directions for use.

5. General directions for use

5.1. Instructions for use

For professional use only.

For wipes reseal the package after opening.

5.2. Risk mitigation measures

Avoid contact with eyes.

Keep out of reach of children

5.3. Particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

First-aid measures general: Move the affected person away from the contaminated area. Get medical advice/attention if you feel unwell. If possible, show this sheet.

IF INHALED: Move to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTRE or a doctor.

IF ON SKIN: Immediately wash skin with plenty of water. Thereafter take off all contaminated clothing and wash it before reuse. Continue to wash the skin with water for 15 minutes. Call a POISON CENTRE or a doctor.

IF IN EYES: Immediately rinse with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing for at least 15 minutes. Call 112/ambulance for medical assistance.

Information to Healthcare personnel/doctor:

The eyes should also be rinsed repeatedly on the way to the doctor if eye exposure to alkaline chemicals (pH > 11), amines and acids like acetic acid, formic acid or propionic acid.

IF SWALLOWED: Immediately rinse mouth. Give something to drink, if exposed person is able to swallow. Do NOT induce vomiting. Call 112/ambulance for medical assistance.

Accidental release measures: Stop leak if safe to do so. Remove ignition sources. Use special care to avoid static electric charges.

No open flames. No smoking. Prevent entry to sewers and public waters. Wipe up with absorbent material (for example cloth). Soak up spills with inert solids, such as clay or diatomaceous earth as soon as possible. Take up mechanically (sweeping, shovelling).

Dispose of in accordance with relevant local regulations.

5.4. Instructions for safe disposal of the product and its packaging

Disposal must be done according to official regulations. Do not empty into drains. Do not dispose of with domestic waste. Dispose of contents/container to an authorised waste collection point. Empty the packaging completely prior to disposal. When totally empty, containers are recyclable like any other packing.

5.5. Conditions of storage and shelf-life of the product under normal conditions of storage

Shelf-life: 24 months

Store in dry, cool, well-ventilated area. Keep container tightly closed. Keep out of direct sunlight.

Recommended storage temperature: 0-30°C

Do not store at temperatures below 0°C

Do not store near food, drink and animal feedingstuff. Keep away from combustible material.

6. Other information