

Summary of product characteristics for a biocidal product

Product name: PRIM VERT 4D

Product type(s): PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT04 - Food and feed area (Disinfectants)

PT04 - Food and feed area (Disinfectants)

PT04 - Food and feed area (Disinfectants)

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

PT04 - Food and feed area (Disinfectants)

Authorisation number: FR-2023-0071

R4BP 3 asset reference number: FR-0021510-0061

Table Of Contents

Administrative information	1
1.1. Trade names of the product	1
1.2. Authorisation holder	1
1.3. Manufacturer(s) of the biocidal products	1
1.4. Manufacturer(s) of the active substance(s)	2
2. Product composition and formulation	2
2.1. Qualitative and quantitative information on the composition of the biocidal product	2
2.2. Type of formulation	2
3. Hazard and precautionary statements	3
4. Authorised use(s)	3
5. General directions for use	26
5.1. Instructions for use	26
5.2. Risk mitigation measures	26
5.3. Particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment	26
5.4. Instructions for safe disposal of the product and its packaging	26
5.5. Conditions of storage and shelf-life of the product under normal conditions of storage	26
6. Other information	27

Administrative information

1.1. Trade names of the product

PRIM VERT 4D
CLARINE NATURA S3D
BPRO Nettoyant détartrant désinfectant Sanitaires
Blutec 4D
DDA400 PAE2

1.2. Authorisation holder

Name and address of the authorisation holder	Name	SOPRODIS
	Address	44 RUE DU LANGUEDOC 11200 LEZIGNAN CORBIERES France
Authorisation number	FR-2023-0071 1-7	
R4BP 3 asset reference number	FR-0021510-0061	
Date of the authorisation	19/12/2023	
Expiry date of the authorisation	18/12/2033	

1.3. Manufacturer(s) of the biocidal products

Name of the manufacturer	SOPRODIS
Address of the manufacturer	44 Rue du LANGUEDOC 11200 LEZIGNAN CORBIERES France
Location of manufacturing sites	44 Rue du LANGUEDOC 11200 LEZIGNAN CORBIERES France

1.4. Manufacturer(s) of the active substance(s)

Active substance	1322 - L-(+)-lactic acid
Name of the manufacturer	Corbion Purac Bioquimica sa
Address of the manufacturer	Gran Vial 19-25 08160 MONTMELÓ Spain
Location of manufacturing sites	Gran Vial 19-25 E-08160 MONTMELÓ Spain Arkelsedijk 46 NL-4200 GORINCHEM Netherlands
Active substance	1322 - L-(+)-lactic acid
Name of the manufacturer	Jungbunzlauer S.A
Address of the manufacturer	ZI Portuaire - BP 32 F-67390 Marcklosheim France
Location of manufacturing sites	Jungbunzlauer S.A - ZI Portuaire - BP 32 F-67390 Marcklosheim France

2. Product composition and formulation

2.1. Qualitative and quantitative information on the composition of the biocidal product

Common name	IUPAC name	Function	CAS number	EC number	Content (%)
L-(+)-lactic acid		Active Substance	79-33-4	201-196-2	1,51
Reaction mass of 5-chloro-2-methyl-2H-isothiazol-3-one (EINECS 247-500-7) and 2-methyl-2H-isothiazol-3-one (EINECS 220-239-6)	Reaction mass of 5-chloro-2-methyl-2H-isothiazol-3-one and 2-methyl-2H-isothiazol-3-one	Non-active substance	55965-84-9	611-341-5	0

2.2. Type of formulation

AL - Any other liquid

3. Hazard and precautionary statements

Hazard statements

Causes skin irritation.
Causes serious eye damage.

Precautionary statements

If medical advice is needed, have product container or label at hand.
Keep out of reach of children.
Read carefully and follow all instructions.
Wash hands thoroughly after handling.
IF ON SKIN:Wash with plenty of soap and water.
IF IN EYES:Rinse cautiously with water for several minutes.Remove contact lenses, if present and easy to do. Continue rinsing.
Immediately call a POISON CENTER or doctor/physician.
Specific treatment (see on this label).
If skin irritation occurs:Get medical .
If eye irritation persists:Get medical .
Take off contaminated clothing.And wash it before reuse.
Wear protective gloves/ protective clothing/ eye protection.
Avoid release to the environment.
Dispose of to .

4. Authorised use(s)

4.1 Use description

Use 1 - Disinfection of hard surfaces and equipment by manual liquid spraying – Professionals - PT2 – RTU product (Use 17)

Product type

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

Where relevant, an exact description of the authorised use

-

Target organism(s) (including development stage)

Scientific name:
Common name: Bacteria
Development stage:

Scientific name:

Common name: Yeasts
Development stage:

Scientific name:
Common name: Viruses
Development stage:

Field(s) of use

Indoor

Indoors disinfection in private and public areas: institutions, industries (including cosmetic and pharmaceutical industries), and health care facilities (excluding the hospitals).

Application method(s)

Method: Spraying
Detailed description:
Manual surface spraying.

Application rate(s) and frequencies

Application Rate: -
Dilution (%): 0
Number and timing of application:
Ready to use product.

Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

Professional

Pack sizes and packaging material

100mL to 2L HDPE/PET Bottle

500mL to 1L HDPE/PET Prefilled trigger spray

750mL HDPE Angled bottle

1L HDPE Bottle with handle

5L HDPE Jerrican with distributor pump

5-10-20L LDPE/PET Bag in box (cubitainer)

5 to 30L HDPE Jerrican

60-220L HDPE Drum

1000L HDPE Bulk container (IBC)

4.1.1 Use-specific instructions for use

- For healthcare settings: clean carefully the surfaces before application of the product.

4.1.2 Use-specific risk mitigation measures

For professional user: wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during loading, application and rinsing.

For professional bystander:

-Do not be present in the treatment area during disinfection process by spraying. If it is necessary to be present, wear same PPE as the professional user.

-Do not touch the surface until it is completely dried

General public:

-Do not be present in the treatment area during disinfection process.

-Do not touch the surface until it is rinsed and completely dried

-Children should not be present during disinfection and until the surface is rinsed and dried.

4.1.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.1.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.1.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.2 Use description

Use 2 - Disinfection of hard surfaces (small surfaces) and equipment by manual liquid spraying using a trigger sprayer – Professionals - PT2 – RTU product (Use 18)

Product type	PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	Scientific name: Common name: Bacteria Development stage: Scientific name: Common name: Yeasts Development stage: Scientific name: Common name: Viruses Development stage:
Field(s) of use	Indoor Indoors disinfection in private and public areas: institutions, industries (including cosmetic and pharmaceutical industries), and health care facilities (excluding the hospitals).
Application method(s)	Method: Manual surface spraying with a trigger sprayer Detailed description: Manual surface spraying with a trigger sprayer (liquid/foam spraying).
Application rate(s) and frequencies	Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product. Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

Professional

Pack sizes and packaging material

- 500mL to 1L HDPE/PET Prefilled trigger spray
- 5L HDPE Jerrican with distributor pump
- 5-10-20L LDPE/PET Bag in box (cubitainer)
- 5 to 30L HDPE Jerrican
- 5L HDPE Jerrican with distributor pump
- 60-220L HDPE Drum
- 1000L HDPE Bulk container (IBC)

4.2.1 Use-specific instructions for use

- For healthcare settings: clean carefully the surfaces before application of the product.

4.2.2 Use-specific risk mitigation measures

For professional user :wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during application by trigger spray and rinsing

For professional bystander:

- Do not be present in the treatment area during disinfection process by spraying. If it is necessary to be present, wear same PPE as

the professional user.

-Do not touch the surface until it is completely dried

General public:

-Do not be present in the treatment area during disinfection process.

-Do not touch the surface until it is rinsed and completely dried

-Children should not be present during disinfection and until the surface is rinsed and dried.

4.2.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.2.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.2.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.3 Use description

Use 3 - Disinfection of hard surfaces by wiping / mopping / brushing / scrubbing – Professionals - PT2 – RTU product (Use 19)

Product type	PT02 - Disinfectants and algacides not intended for direct application to humans or animals (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	<p>Scientific name: Common name: Bacteria Development stage:</p> <p>Scientific name: Common name: Yeasts Development stage:</p> <p>Scientific name:</p>

Common name: Viruses
Development stage:

Field(s) of use

Indoor

Indoors disinfection in private and public areas: institutions, industries (including cosmetic and pharmaceutical industries), and health care facilities (excluding the hospitals).

Application method(s)

Method: Wiping / mopping / brushing / scrubbing
Detailed description:
Wiping/mopping/brushing/scrubbing without mechanical action.

Application rate(s) and frequencies

Application Rate: -
Dilution (%): 0
Number and timing of application:
Ready to use product.

Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

Professional

Pack sizes and packaging material

100mL to 2L HDPE/PET Bottle
500mL to 1L HDPE/PET Prefilled trigger spray
750mL HDPE Angled bottle
1L HDPE Bottle with handle
5L HDPE Jerrican with distributor pump
5-10-20L LDPE/PET Bag in box (cubitainer)
5 to 30L HDPE Jerrican
60-220L HDPE Drum
1000L HDPE Bulk container (IBC)



4.3.1 Use-specific instructions for use

- For healthcare settings: clean carefully the surfaces before application of the product.

4.3.2 Use-specific risk mitigation measures

For professional user: wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during mixing and loading, application and rinsing.

For professional bystander :

- Do not touch the surface until it is completely dried

For general public:

- Do not touch the surface until it is rinsed and completely dried
- Children should not be present during disinfection and until the surface is rinsed and dried.

4.3.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.3.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.3.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.4 Use description

Use 4 - Disinfection of toilet bowls and sanitary facilities by direct spreading/flooding – Professionals - PT2 – RTU product (Use 20)

Product type	PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	Scientific name: Common name: Bacteria Development stage: Scientific name: Common name: Yeasts Development stage: Scientific name: Common name: Viruses Development stage:
Field(s) of use	Indoor Indoors disinfection in private and public areas: institutions, industries.
Application method(s)	Method: Spreading / flooding Detailed description: Direct spreading/flooding.
Application rate(s) and frequencies	Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product. Contact time: - Bacteria and yeasts: 15 minutes, 20°C - Enveloped viruses: 15 min, 20°C - Virus: 60 minutes, 20°C
Category(ies) of users	Professional
Pack sizes and packaging material	100mL to 2L HDPE/PET Bottle

750mL HDPE Angled bottle
1L HDPE Bottle with handle
5L HDPE Jerrican with distributor pump
5-10-20L LDPE/PET Bag in box (cubitainer)
5 to 30L HDPE Jerrican
60-220L HDPE Drum
1000L HDPE Bulk container (IBC)

4.4.1 Use-specific instructions for use

-

4.4.2 Use-specific risk mitigation measures

For professional user: wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during pouring and brushing.

4.4.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.4.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.4.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.5 Use description

Use 5 - Disinfection of hard surfaces and equipment by manual liquid spraying – Professionals - PT4 – RTU product (Use 21)

Product type	PT04 - Food and feed area (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	Scientific name: Common name: Bacteria Development stage: Scientific name: Common name: Yeasts Development stage: Scientific name: Common name: Viruses Development stage:
Field(s) of use	Indoor Indoors disinfection in agri-food industries (excluding milk industries), food and feed areas (collective central kitchens, food shops and restaurants).
Application method(s)	Method: Spraying Detailed description: Manual surface spraying.
Application rate(s) and frequencies	Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product. Contact time: - Bacteria and yeasts: 15 minutes, 20°C - Enveloped viruses: 15 min, 20°C - Virus: 60 minutes, 20°C
Category(ies) of users	Professional
Pack sizes and packaging material	100mL to 2L HDPE/PET Bottle

500mL to 1L HDPE/PET Prefilled trigger spray

750mL HDPE Angled bottle

1L HDPE Bottle with handle

5L HDPE Jerrican with distributor pump

5-10-20L LDPE/PET Bag in box (cubitainer)

5 to 30L HDPE Jerrican

60-220L HDPE Drum

1000L HDPE Bulk container (IBC)

4.5.1 Use-specific instructions for use

-

4.5.2 Use-specific risk mitigation measures

For professional user :wear gloves, protective coverall and chemical googles (material to be specified by the authorisation holder within the product information) during application by spray and rinsing.

For professional bystander:

-Do not be present in the treatment area during disinfection process by spraying. If it is necessary to be present, wear same PPE as the professional user.

-Do not touch the surface until it is completely dried.

General public:

-Do not be present in the treatment area during disinfection process.

-Do not touch the surface until it is rinsed and completely dried

-Children should not be present during disinfection and until the surface is rinsed and dried.

4.5.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.5.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.5.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.6 Use description

Use 6 - Disinfection of hard surfaces (small surfaces) and equipment by manual liquid spraying using a trigger sprayer – Professionals - PT4 – RTU product (Use 22)

Product type	PT04 - Food and feed area (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	Scientific name: Common name: Bacteria Development stage: Scientific name: Common name: Yeasts Development stage: Scientific name: Common name: Viruses Development stage:
Field(s) of use	Indoor Indoors disinfection in agri-food industries (excluding milk industries), food and feed areas (collective central kitchens, food shops and restaurants).
Application method(s)	Method: Manual surface spraying with a trigger sprayer Detailed description: Manual surface spraying with a trigger sprayer (liquid/foam spraying).
Application rate(s) and frequencies	Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product. Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

Professional

Pack sizes and packaging material

500mL to 1L HDPE/PET Prefilled trigger spray

5L HDPE Jerrican with distributor pump

5-10-20L LDPE/PET Bag in box (cubitainer)

5 to 30L HDPE Jerrican

5L HDPE Jerrican with distributor pump

5-10-20L LDPE/PET Bag in box (cubitainer)

5 to 30L HDPE Jerrican

60-220L HDPE Drum

1000L HDPE Bulk container (IBC)

4.6.1 Use-specific instructions for use

-

4.6.2 Use-specific risk mitigation measures

For professional user :wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during application by trigger spray and rinsing

For professional bystander:

-Do not be present in the treatment area during disinfection process by spraying. If it is necessary to be present, wear same PPE as the professional user.

-Do not touch the surface until it is completely dried

General public:

-Do not be present in the treatment area during disinfection process.

-Do not touch the surface until it is rinsed and completely dried

-Children should not be present during disinfection and until the surface is rinsed and dried.

4.6.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.6.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.6.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.7 Use description

Use 7 - Disinfection of hard surfaces by wiping / mopping / brushing / scrubbing – Professionals - PT4 – RTU product (Use 23)

Product type

PT04 - Food and feed area (Disinfectants)

Where relevant, an exact description of the authorised use

-

Target organism(s) (including development stage)

Scientific name:
Common name: Bacteria
Development stage:

Scientific name:
Common name: Yeasts
Development stage:

Scientific name:
Common name: Viruses
Development stage:

Field(s) of use

Indoor
Indoors disinfection in agri-food industries (excluding milk industries), food and feed areas (collective central kitchens, food shops and restaurants).

Application method(s)

Method: Wiping / mopping / brushing / scrubbing
Detailed description:
Wiping/mopping/brushing/scrubbing without mechanical action.

Application rate(s) and frequencies

Application Rate: -
Dilution (%): 0
Number and timing of application:
Ready to use product.

Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

Professional

Pack sizes and packaging material

100mL to 2L HDPE/PET Bottle
500mL to 1L HDPE/PET Prefilled trigger spray
750mL HDPE Angled bottle
1L HDPE Bottle with handle
5L HDPE Jerrican with distributor pump
5-10-20L LDPE/PET Bag in box (cubitainer)
5 to 30L HDPE Jerrican
60-220L HDPE Drum

1000L HDPE Bulk container (IBC)

4.7.1 Use-specific instructions for use

-

4.7.2 Use-specific risk mitigation measures

For professional user: wear gloves, protective coverall and chemical goggles (material to be specified by the authorisation holder within the product information) during mixing and loading, application and rinsing.

For professional bystander :

-Do not touch the surface until it is completely dried

For general public:

-Do not touch the surface until it is rinsed and completely dried

-Children should not be present during disinfection and until the surface is rinsed and dried.

4.7.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.7.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.7.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

-

4.8 Use description

Use 8 - Disinfection of hard surfaces by wiping / mopping / brushing / scrubbing – General public - PT2 – RTU product (Use 25)

Product type	PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	<p>Scientific name: Common name: Bacteria Development stage:</p> <p>Scientific name: Common name: Yeasts Development stage:</p> <p>Scientific name: Common name: Viruses Development stage:</p>
Field(s) of use	<p>Indoor</p> <p>Indoors disinfection in private areas, households.</p>
Application method(s)	<p>Method: Wiping / mopping / brushing / scrubbing Detailed description: Wiping/mopping/brushing/scrubbing without mechanical action.</p>
Application rate(s) and frequencies	<p>Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product.</p> <p>Contact time:</p> <ul style="list-style-type: none"> - Bacteria and yeasts: 15 minutes, 20°C - Enveloped viruses: 15 min, 20°C - Virus: 60 minutes, 20°C
Category(ies) of users	General public (non-professional)
Pack sizes and packaging material	<p>100mL to 2L HDPE/PET Bottle</p> <p>500mL to 1L HDPE/PET Prefilled trigger spray</p> <p>1L HDPE Bottle with handle</p> <p>5L HDPE Jerrican with distributor pump</p>

10L HDPE Jerrican with distributor pump

4.8.1 Use-specific instructions for use

-

4.8.2 Use-specific risk mitigation measures

For non professional user during loading, application and rinsing :

- Wash hands after use
- Avoid contact with eyes and skin
- Avoid splashes and spills
- The packaging must be adapted with a child proof closure

For general public :

- Do not touch the surface until it is rinsed and totally dried
- Children should not be present during disinfection and until the surface is rinsed and dry.

4.8.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.8.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.8.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

- Keep out of reach of children and non-target animals/pets.

4.9 Use description

Use 9 - Disinfection of toilets bowls and sanitary facilities by direct spreading/flooding – General public - PT2 – RTU product (Use 26)

Product type

PT02 - Disinfectants and algaecides not intended for direct application to humans or animals (Disinfectants)

Where relevant, an exact description of the authorised use

-

Target organism(s) (including development stage)

Scientific name:
Common name: Bacteria
Development stage:

Scientific name:
Common name: Yeasts
Development stage:

Scientific name:
Common name: Viruses
Development stage:

Field(s) of use

Indoor

Indoors disinfection in private areas, households.

Application method(s)

Method: Spreading / flooding
Detailed description:
Direct spreading/flooding.

Application rate(s) and frequencies

Application Rate: -
Dilution (%): 0
Number and timing of application:
Ready to use product.

Contact time:

- Bacteria and yeasts: 15 minutes, 20°C
- Enveloped viruses: 15 min, 20°C
- Virus: 60 minutes, 20°C

Category(ies) of users

General public (non-professional)

Pack sizes and packaging material

100mL to 2L HDPE/PET Bottle

750mL HDPE Angled bottle

1L HDPE Bottle with handle

5L HDPE Jerrican with distributor pump

10L HDPE Jerrican with distributor pump

4.9.1 Use-specific instructions for use

-

4.9.2 Use-specific risk mitigation measures

For non professional user during application and rinsing :

- Wash hands after use
- Avoid any contact with eyes and skin
- Avoid splashes and spills
- The packaging must be adapted with a child proof closure

For general public :

- Do not touch the surface until it is rinsed and totally dried
- Children should not be present during disinfection and until the surface is rinsed and dry

4.9.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.9.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.9.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

- Keep out of reach of children and non-target animals/pets.

4.10 Use description

Use 10 - Disinfection of hard surfaces by wiping / mopping / brushing / scrubbing – General public - PT4 – RTU product (Use 28)

Product type	PT04 - Food and feed area (Disinfectants)
Where relevant, an exact description of the authorised use	-
Target organism(s) (including development stage)	Scientific name: Common name: Bacteria Development stage: Scientific name: Common name: Yeasts Development stage: Scientific name: Common name: Viruses Development stage:
Field(s) of use	Indoor Indoors disinfection in private areas, domestic kitchens.
Application method(s)	Method: Wiping / mopping / brushing / scrubbing Detailed description: Wiping/mopping/brushing/scrubbing without mechanical action.
Application rate(s) and frequencies	Application Rate: - Dilution (%): 0 Number and timing of application: Ready to use product. Contact time: - Bacteria and yeasts: 15 minutes, 20°C - Enveloped viruses: 15 min, 20°C - Virus: 60 minutes, 20°C
Category(ies) of users	General public (non-professional)
Pack sizes and packaging material	100mL to 2L HDPE/PET Bottle 500mL to 1L HDPE/PET Prefilled trigger spray

1L HDPE Bottle with handle
5L HDPE Jerrican with distributor pump
10L HDPE Jerrican with distributor pump

4.10.1 Use-specific instructions for use

-

4.10.2 Use-specific risk mitigation measures

For non professional user during application and rinsing :

- Wash hands after use
- Avoid contact with eyes and skin
- Avoid splashes and spills
- The packaging must be adapted with a child proof closure

For general public :

- Do not touch the surface until it is rinsed and totally dried
- Children should not be present during disinfection and until the surface is rinsed and dry.

4.10.3 Where specific to the use, the particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

-

4.10.4 Where specific to the use, the instructions for safe disposal of the product and its packaging

-

4.10.5 Where specific to the use, the conditions of storage and shelf-life of the product under normal conditions of storage

- Keep out of reach of children and non-target animals/pets.

5. General directions for use

5.1. Instructions for use

- Comply with the instructions for use.
- Apply only on non porous surfaces.
- Inform the registration holder if the treatment is ineffective.
- Products have been tested against bacteria, including *Enterobacter cloacae*, *Salmonella Typhimurium*, *Campylobacter jejuni* and *Listeria monocytogenes* at 20°C against virus including bovine coronavirus, rotavirus and influenza virus at 40°C.

5.2. Risk mitigation measures

-

5.3. Particulars of likely direct or indirect effects, first aid instructions and emergency measures to protect the environment

- IF ON SKIN: Take off all contaminated clothing and wash it before reuse. Wash skin with water. If skin irritation occurs: Get medical advice.
- IF IN EYES: Immediately rinse with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing for 5 minutes. Call a poison centre or a doctor
- IF SWALLOWED: Rinse mouth. Give something to drink, if exposed person is able to swallow. Do NOT induce vomiting. Call a poison centre or a doctor
- IF INHALED: If symptoms occur call a POISON CENTRE or a doctor. If medical advice is needed, have product container or label at hand.

5.4. Instructions for safe disposal of the product and its packaging

- Do not discharge unused product on the ground, into water courses, into pipes (sink, toilets...) nor down the drains.
- Dispose of unused product, its packaging and all other waste in accordance with local regulations.

5.5. Conditions of storage and shelf-life of the product under normal conditions of storage

- Protect from frost.
- Keep away from direct sunlight.
- Shelf-life = 2 years.

6. Other information

-